

Figure Search

Figure	Description
0.001 [01]	FILTERS AND CAPACITIES
0.001(00)	FUEL FILTER & OIL FILTER ELEMENTS
0.002(00)	HYDRAULIC SERVICE COMPONENTS (FITTINGS)
0.003(00)	HYDRAULIC SERVICE COMPONENTS (FITTINGS)
0.004(00)	HYDRAULIC SERVICE COMPONENTS (4-BOLT FLANGE CAPS)
0.005(00)	SPANNER WRENCHES, LUBRICANTS
1.000(00)	UPPER FRAME ASSEMBLY LC52F00169P1
1.001(00)	UPPER FRAME GROUP (H&W) LC52FU0009F1
1.002(00)	FRAME, UPP (REWORK) LONG REACH LC52FU0008P1
1.003(00)	COUNTERWEIGHT INSTALLATION LC60C00071F1
1.004(00)	COUNTERWEIGHT INSTALLATION (LONG REACH) LC60CU0005F1
1.004(01)	LAMP, FLASHER YM80S00001F1 & F2
1.005(00)	ENGINE INSTALLATION, (LC02P00034F1)
1.006(00)	RADIATOR INSTALLATION, (LC05P00042F1)
1.006(01)	RADIATOR ASSEMBLY, (LC05P00043F1)
1.007(00)	RADIATOR GROUP LC05P00036F1
1.008(00)	AIR CLEANER ASSEMBLY LC11P00016F1
1.009(00)	MUFFLER ASSEMBLY (LC12P00011F1)
1.010(00)	FUEL LINES LC21P00010F1
1.011(00)	FUEL TANK INSTALLATION LC20P00035F1
1.012(00)	HYDRAULIC TANK ASSEMBLY LC33H00043F1
1.013(00)	POWER TAKE OFF ASSEMBLY LC30P00010F1
1.014(00)	COUPLING, HUB LC30P01023F1
1.015(00)	SWING MOTOR - INSTALLATION (LC32W00008F1)
1.016(00)	VALVE INSTALLATION, MAIN LC64H00113F1 & YN64H00190F1 (NIBBLER & BREAKER)
1.016(01)	CONTROL VALVE INSTAL - NIBBLER AND BREAKER (YN64H00338F1)
1.016(02)	VALVE ASSEMBLY, OVERLOAD RELIEF (YN22V00035F1)
1.017(00)	HYDRAULIC LINES PUMP SUCTION, DELIVERY (PUMP-TO-HYDRAULIC VALVE) LC30H00030F1 PAGE 1 OF 2
1.018(00)	HYDRAULIC LINES PUMP SUCTION, DELIVERY (PUMP-TO-HYDRAULIC VALVE) LC30H00030F1 PAGE 2 OF 2
1.019(00)	UPPER HYDRAULIC LINES - MAIN LC03H00054F1 (PAGE 1 OF 2)
1.020(00)	UPPER HYDRAULIC LINES - MAIN LC03H00054F1 (PAGE 2 OF 2)
1.022(00)	HYDRAULIC LINES - SWIVEL LC19H00014F1
1.023(00)	UPPER HYDRAULIC LINES RETURN LC03H00027F1
1.024(00)	CONTROLS, OPERATORS YN03M00148F1
1.024(01)	CONTROLS, OPERATORS (NO BOOST) LONG REACH YN03M00180F1
1.024(02)	CONTROLS, OPERATORS (HAND NIBBLER AND BREAKER) YN03M00181F1
1.025(00)	CONTROLS, OPERATORS YN03M00153F1 PAGE 1 OF 2
1.025(01)	CONTROLS, OPERATORS YN03M00153F1 PAGE 2 OF 2
1.026(00)	CONTROL BOX ASSY YN03M00149F1
1.027(00)	GRIP ASSY YN03M01870F1
1.027(01)	GRIP ASSY YN03M01974F1
1.028(00)	RADIO INSTALLATION YN54E00010F1
1.029(00)	ARM REST YN25M01180F1
1.029(01)	ARM REST YN25M01183F1
1.030(00)	LEVER ASSY, PROPEL YN50M00015F1
1.030(01)	PEDAL ASSY YN55M00004F1
1.031(00)	CONTROL LINES, REMOTE YN68H00129F1 PAGE 1 OF 3

Figure Search

Figure	Description
1.032(00)	CONTROL LINES, REMOTE YN68H00129F1 PAGE 2 OF 3
1.033(00)	CONTROL LINES, REMOTE YN68H00129F1 PAGE 3 OF 3
1.034(00)	CONTROL LINES, MAIN LC06H00045F1 PAGE 1 OF 2
1.035(00)	CONTROL LINES, MAIN LC06H00045F1 PAGE 2 OF 2
1.036(00)	CONTROL LINES, VALVE LC64H00104F1 PAGE 1 OF 2
1.037(00)	CONTROL LINES, VALVE LC64H00104F1 PAGE 2 OF 2
1.038(00)	CONTROL LINES, VALVE LC64H00105F1 NIBBLER & BREAKER
1.039(00)	CONTROL LINES, PUMP LC06H00042F1
1.040(00)	CONTROL LINES, PROPEL LC62H00014F1
1.041(00)	CONTROL LINES, BLOCK LC64H00088F1
1.042(00)	CONTROL LINES, BLOCK LC64H00143F1 STD & BASE
1.043(00)	CONTROL LINES, BLOCK LC64H00150F1 BASE
1.044(00)	CONTROL LINES, BLOCK LC64H00150F1 STD
1.045(00)	CONTROL LINES, BLOCK YN64H00183F1 STD
1.046(00)	PLATE INSTALL, FLOOR YN03M00162F1
1.047(00)	MIRROR INSTAL YN52C00017F1
1.048(00)	CAB INSTALL YN02C00151F1
1.049(00)	CAB ASSY YN02C00156F1 PAGE 1 OF 3
1.050(00)	CAB ASSY YN02C00156F1 PAGE 2 OF 3
1.051(00)	CAB ASSY YN02C00156F1 PAGE 3 OF 3
1.052(00)	CAB, WINDOW, ROOF YN02C03654F1
1.053(00)	CAB - WINDOW, FRONT YN50C00005F1
1.054(00)	CAB DOOR PAGE 1 OF 2 YN51C00010F2
1.055(00)	CAB DOOR PAGE 2 OF 2 YN51C00010F2
1.056(00)	SEAT INSTALLATION YN25M00071F1
1.057(00)	SEAT BELT ASSY YN25M00053F1
1.058(00)	GUARD INSTALLATION LC21C00034F1 PAGE 1 OF 3
1.059(00)	GUARD INSTALLATION LC21C00034F1 PAGE 2 OF 3
1.060(00)	GUARD INSTALLATION LC21C00034F1 PAGE 3 OF 3
1.060(01)	GUARD INSTAL - TOOL BOX ASSY
1.061(00)	GUARD INSTALLATION LC21C00024F1
1.062(00)	GUARD INSTALLATION LC21C00038F1
1.063(00)	GUARD INSTALLATION LC21C00036F1
1.064(00)	COVER ASSEMBLY, UNDER LC24C00022F1
1.065(01)	INSTRUMENT PANEL ASSEMBLY YN17M00059F1 PAGE 1 OF 3
1.065(02)	INSTRUMENT PANEL ASSEMBLY YN17M00059F1 PAGE 2 OF 3
1.065(03)	INSTRUMENT PANEL ASSEMBLY YN17M00059F1 PAGE 3 OF 3
1.066(01)	INSTRUMENT PANEL ASSEMBLY (NIBBLER & BREAKER) YN17M00056F1 PAGE 1 OF 3
1.066(02)	INSTRUMENT PANEL ASSEMBLY (NIBBLER & BREAKER) YN17M00056F1 PAGE 2 OF 3
1.066(03)	INSTRUMENT PANEL ASSEMBLY (NIBBLER & BREAKER) YN17M00056F1 PAGE 3 OF 3
1.067(00)	GAUGE ASSEMBLY, CLUSTER (YN59S00021F2)
1.071(00)	CONTROLLER INSTALLATION LC22E00097F1
1.072(00)	RELAY BOX ASSY YN24E00019F1
1.073(00)	RELAY ASSY YN24E00017F1 & YN77S00029F1
1.074(00)	BATTERY ASSY LC72E00007F1
1.075(00)	AIR CONDITIONER LC20M00033F1 PAGE 1 OF 3
1.076(00)	AIR CONDITIONER LC20M00033F1 PAGE 2 OF 3

Figure Search

Figure	Description
1.077(00)	AIR CONDITIONER LC20M00033F1 PAGE 3 OF 3
1.078(00)	AIR CONDITIONER ASSY YN20M00113F1
1.079(00)	DRIER ASSY, AIR
1.080(00)	COMPRESSOR ASSY, AIR YX91V00001F1
1.081(00)	CONDITIONER ASSEMBLY, AIR
1.082(00)	CONDITIONER ASSEMBLY, AIR
1.083(00)	ELECT ASSY, UPP LC03E00008F1
1.084(00)	LAMP MOUNTING, UPP YN80E00049F1
1.084(01)	LAMP ASSEMBLY (YT80S00002F2)
1.085(00)	HARNESS ASSY, UPP LC13E00048F1 PAGE 1 OF 3
1.086(00)	HARNESS ASSY, UPP LC13E00048F1 PAGE 2 OF 3
1.087(00)	HARNESS ASSY, UPP LC13E00048F1 PAGE 3 OF 3
1.088(00)	HARNESS ASSY. CAB LC14E00023F1
1.089(01)	HARNESS ASSY, CAB YN14E00056F1
1.090(00)	HARNESS ASSEMBLY, UPP PLATE, FLOOR LC13E00049F1
1.091(00)	HARNESS ASSEMBLY ENGINE LC16E00010F1
1.092(00)	HARNESS ASSEMBLY BOOM WORK LAMP LB15E00001F2
2.000(00)	LOWER INSTALLATION STANDARD GROUP LC01F00021F1
2.001(00)	MOTOR INSTAL, PROPEL (H & W) LC53DU0003F1
2.002(00)	LOWER FRAME GROUP (STD GUIDE) (H & W) LC01FU0003F1
2.003(00)	LOWER FRAME GROUP (FULL GUIDE) LC01FU0003F2
2.004(00)	FRAME ASSY, LOW (H & W) LC02FU0019P1
2.005(00)	SLEWING RING ASSEMBLY LC40F00019F1
2.006(00)	IDLER LC52D00025F1
2.007(00)	IDLER ASSEMBLY LC52D00026F1
2.008(00)	IDLER ASSEMBLY LC52D00032F1
2.009(00)	IDLER ADJUST ASSEMBLY LC54D00009F1
2.010(00)	TRACK ROLLER ASSEMBLY LC64D00004F3
2.011(00)	UPPER ROLLER ASSEMBLY LC64D00003F1
2.012(00)	ROLLER ASSY, UPP (H & W) LC64DU0019F1
2.013(00)	SHOE ASSEMBLY 800MM LC60D00016F3
2.014(00)	LOWER HYDRAULIC LINES LC02H00022F1 PAGE 1 OF 2
2.015(00)	LOWER HYDRAULIC LINES LC02H00022F1 PAGE 2 OF 2
2.016(00)	COVER ASSY, UNDER LC24C00027F1
2.017(00)	BLOCK INSTALL LC02F0123P1
3.001(00)	BOOM GROUP - LUBE - STD - 6.5M (21 FT - 4 IN) LC02B00155F1 PAGE 1 OF 2
3.001(01)	BOOM GROUP - LUBRICATION (AFTER DEC 2008)
3.001(02)	BOOM GROUP - LUB - BOOM CYL LUB KIT
3.002(00)	BOOM ASSEMBLY 6.5M (21 FT - 4 IN) LC02B00165F1
3.002(01)	BOOM INSTAL STANDARD - 6.5M (21 FT - 4 IN) LC02B00155F1 PAGE 2 OF 2
3.003(00)	BOOM ASSEMBLY (6.0M / 19 FT - 7 IN) (MASS EXCAVATOR) LC02BU0008F1
3.004(00)	HYD LINES, BOOM STD LC42H00175F1
3.005(00)	HYD LINES, BOOM 6.5 M (21FT - 4 IN) (NIBBLER AND BREAKER) LC42H00178F1 PAGE 1 OF 2
3.006(00)	HYD LINES, BOOM 6.5 M (21FT - 4 IN) (NIBBLER AND BREAKER) LC42H00178F1 PAGE 2 OF 2
3.007(00)	HYD LINES, BOOM (NIBBLER & BREAKER) LC42H00169F1
3.008(00)	LAMP MOUNTING - BOOM YN80E00026F1
3.009(00)	ARM GROUP, 3.3M (10FT - 10IN) 4.15M (13FT - 9IN) (LC12B00266F1, LC12B00383F1 & LC12B00392F1)

Figure Search

Figure	Description
3.010.1(00)	ARM INSTALLATION (LONG REACH), (LC12B00392F1)
3.010.2(00)	ARM INSTALLATION (MASS EXCAVATOR), (LC12BU0024F1)
3.011(00)	ARM ASSEMBLY 3.3M (10FT - 10IN) LC12B00383F1
3.012(00)	ARM GROUP (LONG REACH) YM12B00044FD
3.013(00)	ARM, LONG REACH LC12BU0014F1
3.014(00)	ARM, LONG REACH (ROTATION) LC12B00418F1
3.014(01)	ARM, LONG REACH (ROTATION) LC12B00420P1
3.015(00)	ARM, LONG REACH (NIBBLER & BREAKER) LC12B00413F1
3.016(00)	ARM - ROTATION LC12B00387F1
3.016(01)	ARM - ROTATION LC12B00344P1
3.017(00)	ARM SHORT (ROTATION) LC12B00406F1
3.017(01)	ARM SHORT (ROTATION) LC12B00493P1
3.018(00)	ARM ASSEMBLY, (MASS EXCAVATOR) (LC12BU0015F1)
3.019(00)	HYDRAULIC LINES - ARM 3.3M (10FT 10IN) LC43H00081F1
3.025(00)	HYD LINES - ARM LONG REACH LC43H00121F1
3.026(00)	HYD LINES - SHORT ARM (NIBBLER & BREAKER) LC43H00107F1
3.027(00)	HYD LINES, LONG ARM (NIBBLER & BREAKER) LC43H00122F1
3.028(00)	BUCKET - INSTALLATION LC61B00088F1
3.029(00)	BUCKET - INSTALLATION (LONG REACH) YM61B00002F1
3.030(00)	CASE ASSY, GEAR YN46W00001F2
3.031(00)	CASE ASSY, GEAR YN46W00002F6
3.032(00)	PUMP - GEAR YF10V00003F1
3.033(00)	VALVE INSTALLATION (ROTATION) YN64H00196F1
3.033(01)	VALVE YN30V00108F1
3.034(00)	CYLINDER INSTALLATION, BUCKET (LONG REACH) YM12B00027F1
3.035(00)	CYLINDER, BUCKET YM01V00009F1 LONG REACH
3.036(00)	BOOM HYDRAULIC LINES, MASS EXCAVATOR (LC42HU0005F1)
3.037(01)	HYD LINES, BOOM, MASS EXCAVATOR (NIBBLER & BREAKER) (LC42HU0008F1), PAGE 1 OF 2
3.037(02)	HYD LINES, BOOM, MASS EXCAVATOR (NIBBLER & BREAKER) (LC42HU0008F1), PAGE 2 OF 2
3.038(00)	HYD LINES, ARM (MASS EXCAVATOR) (LC43HU0005F1)
3.039(00)	HYDRAULIC LINES - ARM (MASS EXCAVATOR / NIBBLER & BREAKER) (LC43HU0006F1)
3.040(00)	VALVE ASSEMBLY, (24100P3133F1)
4.001(00)	TOOLS & ACCESSORIES LC01T00032F4
4.002(00)	ELEMENT KIT LC30T00005F7
1.068(01)	CAB FRONT GUARD
1.068(02)	CAB FRONT GUARD
1.068(03)	CAB FRONT GUARD
5.001(00)	VALVE INSTALLATION YN64H00190F1
5.002(00)	HYD LINES, UPPER (NIBBLER & BREAKER) LC03H00055F1
5.003(00)	CONTROLS, OPERATORS (PEDAL ASSY) YN55M0004F1
5.004(00)	CONTROL LINES, VALVE (NIBBLER & BREAKER) LC64H000105F1
5.005(00)	CONTROL LINES, VALVE (NIBBLER & BREAKER W/ROTATION) LC64H00159F1
5.006(00)	CONTROL LINES, VALVE (W/ROTATION) LC64H00160F1
5.007(00)	CONTROL LINES, MULTI LC64H00140F1
5.008(00)	CONTROL LINES, VALVE (BOOM & ARM SAFETY) LC64H00085F1
5.009(00)	CONTROL LINES, MAIN (ROTATION + NIBBLER & BREAKER) LC06H00057F1
5.010(00)	CONTROL LINES, BLOCK (NIBBLER & BREAKER) LC64H00153F1

Figure Search

Figure	Description
5.011(00)	CONTROL LINES, REMOTE (NIBBLER & BREAKER) LC68H00063F1
5.012(00)	INSTRUMENT PANEL ASSY, SWITCH INSTALLATION (NIBBLER & BREAKER) YN50E00021F1
5.013(00)	HYD LINES, BOOM (NIBBLER & BREAKER) LC42H00169F1
5.014(00)	HYD LINES, ARM 3.3M (NIBBLER & BREAKER) LC43H00111F1
5.015(00)	CONNECTOR ASSY (NIBBER & BREAKER) YN43H01646F1
5.016(00)	ARM, SHORT (NIBBLER & BREAKER) LC12B00402F1
5.017(00)	ARM GROUP, SHORT (2.6M) LC12B00408F1
5.018(00)	HYD LINES, ARM, SHORT LC43H00105F1
5.019(00)	HYD LINES, BOOM (ROTATION) LC42H00180F1 PAGE 1 OF 2
5.020(00)	HYD LINES, BOOM (ROTATION) LC42H00180F1 PAGE 2 OF 2
5.021(00)	HYD LINES, BOOM CYLINDER (SAFETY) LC42H00227F1
5.022(00)	HYD LINES, ARM CYLINDER (SAFETY) LC42H00186F1
5.023(00)	HYD LINES, ARM (ROTATION & NIBBLER & BREAKER) LC43H00143F1
5.024(00)	HYD LINES, ARM (ROTATION) LC43H00144F1
5.025(00)	HYD LINES, ARM, LONG (ROTATION & NIBBLER & BREAKER) LC43H00146F1
5.026(00)	HYD LINES, ARM, LONG (ROTATION) LC43H00147F1
5.027(00)	HYD LINES, ARM SHORT (ROTATION + NIBBLER & BREAKER) LC43H00149F1
5.028(00)	HYD LINES, ARM, SHORT (ROTATION) LC43H00150F1
5.029(00)	HYD LINES, PUMP (ROTATION) LC30H00037F1
5.029(01)	HYD LINES, PUMP (ROTATION) LC30H00031F1
5.030(00)	HYD LINES, UPP (ROTATION) BASE PAGE 1 OF 2 LC03H00067F1
5.031(00)	HYD LINES, UPP (ROTATION) BASE PAGE 2 OF 2 LC03H00067F1
5.032(00)	HYD LINES, UPP (ROTATION) EXTRA LC03H00067F1
5.033(00)	HYD LINES, UPP (ROTATION W/NIBBLER & BREAKER) (LC03H00063F1), FIGURE 1 OF 3
5.033(01)	HYD LINES, UPPER (ROTATION W/NIBBLER & BREAKER) (LC03H00063F1), FIGURE 2 OF 3
5.033(02)	HYD LINES, UPP (ROTATION W/NIBBLER & BREAKER) (LC03H00063F1), FIGURE 3 OF 3
5.034(00)	HYD LINES, LOW (H & W) LC02HU0005F1
5.036(00)	HYD LINES, SWIVEL (H & W) LC19HU0001F1
5.037(00)	HYD LINES, PROPEL (H & W) LC12HU0001F1
5.039(00)	HARNESS ASSY, UPP (NIBBLER & BREAKER, HAND) LC13E00052F1
5.040(00)	HARNESS ASSY, UPP (NIBBLER & BREAKER, ROTATION, HAND) LC13E00051F1
5.041(00)	HARNESS ASSY, UPP (ROTATION) LC13E00056F1
5.042(00)	HARNESS ASSY, UPP (PATTERN CHANGE) LC13E00055F1
5.043(00)	SUN VISOR ASSY YN55C00013F1
5.050(00)	DIA KITS
6.001(00)	MIRROR INSTAL YN52C00019F1
6.002(00)	ALARM ASSY LC53E00007F1
6.003(00)	CAP ASSY YN02B01738F1
6.004(00)	CAP ASSY YN12B02300F1
6.005(00)	SHOE ASSEMBLY 600MM LC60D00016F1
6.006(00)	SHOE ASSEMBLY 600MM (HD) LC60D00016F2
6.007(00)	SHOE ASSEMBLY 700MM DOUBLE GROUSER LC60D00016F5
6.008(00)	SHOE ASSEMBLY 700MM TRIPLE GROUSER LC60D00016F7
6.009(00)	SHOE ASSEMBLY 900MM LC60D00016F4
6.010(00)	SLEWING RING ASSY (H & W) LC40FU0002F1

Figure Search

Figure	Description
6.011(00)	SHOE ASSEMBLY (H & W) 600MM (HD) LC60DU0010F1
6.012(00)	SHOE ASSEMBLY (H & W) 700MM DOUBLE GROUSER LC60DU0010F2
6.013(00)	SHOE ASSEMBLY (H & W) 700MM TRIPLE GROUSER LC60DU0010F3
6.014(00)	SHOE ASSEMBLY (H & W) 800MM LC60DU0010F4
6.015(00)	SHOE ASSEMBLY (H & W) 900MM LC60DU0010F5
6.016(00)	STEP INSTAL YN41CU0002F1-F3
6.017(00)	VANDALISM GUARDS 1 OF 2 YN25C00008F1
6.018(00)	VANDALISM GUARDS 2 OF 2 YN25C00008F1
6.019(00)	BOOM GROUP (MASS EXCAVATOR) LC02BU0017F1
88.100.20	HENDRIX QUICK COUPLER CONTROLLER
7.001(00)	NAME PLATE INSTALLATION, LUBRICATION CHART YN22T00333F3
7.002(00)	NAME PLATE INSTALLATION, BOOM LC22T00017F1
7.003(00)	NAME PLATE INSTALLATION, FRAME, LABEL LOCATION YN22T00340F2 PAGE 1 OF 3
7.004(00)	NAME PLATE INSTALLATION, FRAME, LABEL LOCATION YN22T00340F2 PAGE 2 OF 3
7.005(00)	NAME PLATE INSTALLATION, FRAME, LABEL LOCATION YN22T00340F2 PAGE 3 OF 3
7.006(00)	NAME PLATE , FRAME - LABELS YN22T00340F2 PAGE 1 OF 2
7.007(00)	NAME PLATE, FRAME - LABELS YN22T00340F2 PAGE 2 OF 2
7.008(00)	NAME PLATE, CAUTION LABEL YN22T00340F4
7.009(00)	NAME PLATE INSTALLATION, CAB, LABEL LOCATION YN22T00341F1
7.010(00)	NAME PLATE - CAB, LABELS YN22T00341F1
7.011(00)	NAME PLATE INSTALLATION, CAB (NIBBLER & BREAKER), LABEL LOCATION YN22T00341F3
7.012(00)	NAME PLATE INSTALLATION, CAB (NIBBLER & BREAKER) LABEL YN22T00341F3
7.013(00)	NAME PLATE INSTALLATION, (EXTERIOR) LOCATION LC22TU0007F1
7.014(00)	NAME PLATE INSTALLATION, (EXTERIOR) LABELS LC22TU0007F1
7.015(00)	NAME PLATE INSTALLATION, LOCATION LC22T00097F1-F9
7.016(00)	NAME PLATE INSTALLATION, LABEL LC22T00097F1-F3
7.017(00)	NAME PLATE INSTALLATION, LABEL LC22T00097F4-F6
7.018(00)	NAME PLATE INSTALLATION, LABEL LC22T00097F7-F9
7.019(00)	NAME PLATE INSTALLATION, (ANTI-SKID) LABEL LOCATION LC22T00091F1
7.020(00)	NAME PLATE INSTALLATION, (ANTI-SKID) LABEL LC22T00091F1
7.021(00)	NAME PLATE INSTALLATION, (PATTERN CHANGE) LABEL LOCATION YN22T00341F2
7.022(00)	NAME PLATE INSTALLATION, (PATTERN CHANGE) YN22T00341F2
7.023(00)	NAME PLATE INSTALLATION, (PATTERN CHANGE) LABEL LOCATION YN22T00340F3
7.024(00)	NAME PLATE INSTALLATION, (PATTERN CHANGE) YN22T00340F3
7.025(00)	NAME PLATE INSTALLATION, (MASS EXCAVATOR) LC22TU0008F1
7.026(00)	NAME PLATE INSTALLATION, (LONG REACH) YN22T00341F4
8.000(00)	VALVE ASSY, CONTROL LC30V00028F1 (HC001) PAGE 1 OF 5
8.001(00)	VALVE ASSY, CONTROL LC30V00028F1 (HC001) PAGE 2 OF 5
8.002(00)	VALVE ASSY, CONTROL LC30V00028F1 (HC001) PAGE 3 OF 5
8.003(00)	VALVE ASSY, CONTROL LC30V00028F1 (HC001) PAGE 4 OF 5
8.004(00)	VALVE ASSY, CONTROL LC30V00028F1 (HC001) PAGE 5 OF 5
8.005(00)	HYDRAULIC VALVE RELIEF LC22V00011F1
8.006(00)	VALVE ASSY, PORT RELIEF YN22V00002F1-FJ (HC015)

Figure Search

Figure	Description
8.007(00)	VALVE ASSY, CONTROL YN30V00104F1 (HC100)
8.008(00)	MOTOR ASSY (SWING) LC15V00022F1 (HC300)
8.009(00)	REDUCTION ASSY (SWING) LC32W00007F1 (HC310)
8.010(00)	VALVE ASSY, (SWING-REACTIONLESS) YN20V00004F1-F4 (HC315)
8.011(00)	VALVE ASSY, RELIEF YN22V00014F1-FB (HC325)
8.012(00)	MOTOR ASSY, PROPELLING LC15V00023F1 (HC370) PAGE 1 OF 2
8.013(00)	MOTOR ASSY, PROPELLING LC15V00023F1 (HC370) PAGE 2 OF 2
8.014(00)	PUMP ASSY LC10V00014F1 (HC400)
8.015(00)	PUMP ASSY LC10V00020F1 (HC405) PAGE 1 OF 2
8.016(00)	PUMP ASSY LC10V00020F1 (HC405) PAGE 2 OF 2
8.017(00)	REGULATOR ASSY LC10V01005F1 (HC410) PAGE 1 OF 2
8.018(00)	REGULATOR ASSY LC10V01005F1 (HC410) PAGE 2 OF 2
8.019(00)	PUMP ASSY, GEAR YN22V00014F1-FB (HC420)
8.020(00)	CYLINDER ASSY, BOOM LC01V00044F1 (HC600)
8.021(00)	CYLINDER ASSY, ARM LC01V00054F1,F2 (HC650)
8.022(00)	CYLINDER ASSY, BUCKET LC01V00055F1 (HC700)
8.023(00)	VALVE ASSY, PILOT YN30V00080F1 (HC825)
8.024(00)	VALVE ASSY, SOLENOID YN35V00047F1 (HC850)
8.025(00)	VALVE ASSY, SOLENOID YN35V00048F1 (HC851)
8.026(00)	VALVE ASSY, SOLENOID YN35V00049F1 (HC852)
8.027(00)	VALVE ASSY, SOLENOID YN35V00050F1 (HC853)
8.028(00)	VALVE ASSY, SOLENOID YN35V00051F1 (HC854)
8.029(00)	VALVE ASSY, SELECTOR YN30V00117F1 (HC880)
8.030(00)	VALVE ASSY, HOLDING YN28V00019F1, F2 (HC900)
8.031(00)	JOINT ASSY, SWIVEL YN55V00053F1 (HC930)
8.032(00)	VALVE ASSY, PILOT (TRAVEL)
9.002(01)	CYLINDER HEAD 10-00-1 (HINO ENGINE TYPE J08ETM-KSDA)
9.002(02)	CYLINDER HEAD 10-00-2 (HINO ENGINE TYPE J08ETM-KSDA)
9.003(00)	CYLINDER BLOCKS 11-00-1 (HINO ENGINE TYPE J08ETM-KSDA)
9.004(00)	CYLINDER BLOCKS 11-00-2 (HINO ENGINE TYPE J08ETM-KSDA)
9.005(00)	TIMING GEAR COVER & FLY WHEEL HOUSING 11-10 (HINO ENGINE TYPE J08ETM-KSDA)
9.006(00)	MAIN MOVING PARTS 12-00 (HINO ENGINE TYPE J08ETM-KSDA)
9.007(00)	CAMSHAFT AND IDLE GEAR 13-00 (HINO ENGINE TYPE J08ETM-KSDA)
9.008(00)	VALVE SYSTEM 13-10 (HINO ENGINE TYPE J08ETM-KSDA)
9.009(00)	AIR INTAKE AND EXHAUST SYSTEM 13-20-1 (HINO ENGINE TYPE J08ETM-KSDA)
9.010(00)	AIR INTAKE AND EXHAUST SYSTEM 13-20-2 (HINO ENGINE TYPE J08ETM-KSDA)
9.011(00)	LUBRICATION SYSTEM 14-00 (HINO ENGINE TYPE J08ETM-KSDA)
9.012(00)	OIL FILTER 14-51 (HINO ENGINE TYPE J08ETM-KSDA)
9.013(00)	OIL COOLER 14-52 (HINO ENGINE TYPE J08ETM-KSDA)
9.014(01)	FUEL SYSTEM 15-00 (HINO ENGINE TYPE J08ETM-KSDA)
9.014(02)	FUEL SYSTEM (HINO ENGINE TYPE JO8ETM-KSDA)
9.015(00)	FUEL FILTER 15-54 (HINO ENGINE TYPE J08ETM-KSDA)
9.015.01(00)	FUEL FILTER KIT, MODIFCATION (LC32T00017F1)
9.015.02(00)	FUEL FILTER KIT, HARNESS MODIFCATION (LQ13E00074F1)
9.016(00)	COOLING SYSTEM 16-00 (HINO ENGINE TYPE J08ETM-KSDA)
9.017(00)	ELECTRICAL PARTS 18-10-1 (HINO ENGINE TYPE J08ETM-KSDA)
9.018(00)	ELECTRICAL PARTS 18-10-2 (HINO ENGINE TYPE J08ETM-KSDA)

Figure Search

Figure	Description
9.019(00)	ELECTRICAL PARTS 18-10-3 (HINO ENGINE TYPE J08ETM-KSDA)
9.020(00)	TURBOCHARGER 18-30 (HINO ENGINE TYPE J08ETM-KSDA)
9.021(00)	ENGINE ACCESSORY PARTS 18-40 (HINO ENGINE TYPE J08ETM-KSDA)
9.022(00)	ALTERNATOR 19-04 (HINO ENGINE TYPE J08ETM-KSDA)
9.023(00)	STARTER MOTOR 19-05 (HINO ENGINE TYPE J08ETM-KSDA)
9.024(00)	GASKET KIT, ENGINE OVERHAUL 19-91 (HINO ENGINE TYPE J08ETM-KSDA)

0.001 [01] - FILTERS AND CAPACITIES

